

Windows 11 Virtual Machine Setup (VirtualBox)

This section describes how to create the monitored Windows 11 endpoint used for attack simulation.

Steps:

1. Install VirtualBox from virtualbox.org
2. Create a new virtual machine
 - Name: Windows 11 Lab
 - ISO Image: Windows 11 installation ISO
 - RAM: 4–8 GB
 - CPUs: 2–4
 - Storage: 60 GB
 - Enable EFI
3. Install Windows normally
4. Install VirtualBox Guest Additions
 - Enables copy/paste
 - Enables auto-resize
 - Enables drag-and-drop
5. Update Windows and reboot

The VM is now ready for Sysmon installation.

<p>General</p> <p>Name: Soc Automation Operating System: Windows 11 (64-bit)</p>	<p>Preview</p> 
<p>System</p> <p>Base Memory: 5024 MB Processors: 2 Boot Order: Floppy, Optical, Hard Disk TPM Type: v2.0 EFI: Enabled Secure Boot: Enabled Acceleration: Nested Paging, Hyper-V Paravirtualization</p>	
<p>Display</p> <p>Video Memory: 128 MB Graphics Controller: VBoxSVGA Remote Desktop Server: Disabled Recording: Disabled</p>	
<p>Storage</p> <p>Controller: SATA SATA Port 0: Soc Automation_.vdi (Normal, 80.00 GB) SATA Port 1: [Optical Drive] Windows.iso (5.65 GB)</p>	
<p>Audio</p> <p>Host Driver: Default Controller: Intel HD Audio</p>	
<p>Network</p> <p>Adapter 1: Intel PRO/1000 MT Desktop (NAT)</p>	
<p>USB</p> <p>USB Controller: xHCI Device Filters: 0 (0 active)</p>	
<p>Shared folders</p> <p>None</p>	
<p>Description</p> <p>None</p>	